

BELL+HOWELL

HIGH DEFINITION WIRELESS SPEAKER



BH35 User's Guide

Powering BH35 On / Off

Slide the power switch on the back of the speaker to the on position to power ON. You will hear “Bluetooth Mode” and a blue LED will flash quickly to indicate that it is powered on and searching for a Bluetooth source to pair with.

To power the speaker off, slide the power switch on the back of the speaker to the off position.

NOTE: An additional battery icon may appear next to the Bluetooth icon at the top right of your phone/tablet’s screen, indicating the speaker’s battery level. This is compatible only with certain devices.

Connecting BH35 via Bluetooth

Once powered on, the speaker will automatically enter pairing mode. Go into your phone/tablet’s Bluetooth settings and enable Bluetooth. Next, enter the Bluetooth device list and select

Bell+Howell_BH35. After selected, wait a few seconds for the pairing to complete. Once the pairing is successful, you will hear “Paired” from the speaker and the LED will light up solid blue.

NOTE: The BH35 will automatically connect to a previously paired device if the paired device’s Bluetooth radio is powered, enabled and within reachable distance.

Connecting BH35 via Auxiliary Input

If you would like to use a device that is not equipped with Bluetooth technology, simply connect the included auxiliary 3.5mm cable from your device to the Aux-In input at the back of the BH35. Press the MODE button to switch to Auxiliary mode. While connected via Auxiliary, the only controls that will function on the speaker is the PLAY button and volume control. All other functions are controlled from the connected device.

Playing Music from a Memory Card

If you want to play music off a memory card simply insert the memory card with music loaded into the slot on the back of the speaker. The speaker will automatically enter that mode. The speaker controls will work as normal. Simply remove the memory card to exit that mode.

Controlling the Sound on Your BH35

PLAY / PAUSE

Tap the PLAY button.

VOLUME UP / DOWN

Press and hold the MINUS button to decrease the volume. Press and hold the PLUS button to increase the volume.

FORWARD / BACKWARD TRACK

Tap TRACK FORWARD button to skip a track forward. Tap the PREVIOUS TRACK button to go to the previous track.

FAST FORWARD / REWIND

Press and hold TRACK FORWARD button to fast forward. Press and hold the PREVIOUS TRACK button to rewind.

ANSWER / END PHONE CALL

Tap the PLAY button.

DECLINE PHONE CALL

Press and hold the PLAY button.

CHANGING MODES

Press the MODE button to switch between modes.

Answering or Making Calls

If there is an incoming call on your paired phone/tablet, the music will pause and you will hear “Calling” from the BH35 speaker. To answer a call, simply press the PLAY button.

To end a call, simply press the PLAY button. Press and hold the PLAY button to decline a phone call.

NOTE: For best performance and clarity, operate the BH35 within an arm's length. Ensure that the microphone faces your direction.

Charging your BH35

Plug the small end of the included micro USB cable into the micro USB port on the back of the speaker. Plug the other end of the cable into a 5V AC adaptor (not included). Once plugged in, the LED will light up red. It will turn off once the internal battery is fully charged.

NOTE: The BH35 can only be charged with 5V adapters/USB ports. Quick charging devices over 5V may cause damage.

Power Bank

Your BH35 can charge external devices with the built-in power bank. Simply plug in a USB cable to the USB port on the back of the speaker, then plug the other end of the cable into the device

you want charged. Charging will begin automatically.

NOTE: Using the power bank to charge other devices will reduce the battery life of the speaker.

Specifications

Bluetooth Version: 5.0

Built-in Lithium-Ion Battery: 3.7V, 3000mAh

Charging Voltage: 5V

Speaker: 45mm 4Ω 5W x 2


Frequency: 20Hz-20KHz

Distortion: ≤0.1%

Effective Distance: 10M

Elite Brands Inc.,
40 Wall Street, 61st Floor
New York, NY 10005 · Tel: 1-800-441-1100
www.elitebrands.com

Distributed under license of BHH LLC by ELITE BRANDS INC ©2021
www.bellhowellcameras.com

*The  **Bluetooth**™ word mark and logos are registered trademarks owned by the Bluetooth SIG, and any use of such marks by Elite Brands Inc. is under license. Other trademarks and trade names are those of their respective owners.*